


SRD991 Intelligent Positioner

These instructions are to be used as a guide for quick start-up. For more detailed information, please refer to the standard documents "Master Instructions" and "Product Specification Sheet". These can be found on our Website.

1. MOUNTING TO ACTUATORS


During operation, the flat side of the spindle **9** on the back of the positioner must **always** point towards the arrow **26**. The working angle around this position is $\pm 45^\circ$.




Any mechanical backlash may be source of poor control, oscillation and hunting as well as long duration of Autostart. Please use only original mounting parts and ensure that they are correctly mounted and tighten. By not using the original feedback lever or by using them in an inappropriate way, the performance of the positioner may be compromised.

MOUNTING TO LINEAR ACTUATORS

NAMUR Mounting - left hand -




NAMUR Mounting - right hand -



MOUNTING TO LINEAR ACTUATORS (cont'd)


Feedback lever for linear actuators :

The carrier bolt **B** is in the slot of the feedback lever **A** and the compensating spring **F** touches the carrier bolt.




Carrier bolt **B**:

1 threaded sleeve 2 Stud 3 coupling piece




Direct Mounting





MOUNTING TO ROTARY ACTUATORS

- Do not tighten grub screw **4** against the thread of spindle **9**! (see next page).
- When in use the flat side of the spindle **9** must move (0 ↔ 100%) in front of the arrow **26**.



- When the product temperature rises, the drive shaft **1** increases in length. Therefore, the rotary adapter **3** must be mounted so that approx. 1 mm (0.04 in.) of clearance results between the drive shaft **1** and the rotary adapter **3**. This is achieved by placing an appropriate number of washers **5** on the feedback spindle **9** before attaching the rotary adapter. Two washers should result in a clearance of 1 mm.






2. CONNECTIONS

Check before mounting fittings and cable glands that the threads are matching; otherwise the housing can be damaged. The letter "G" on the housing marks where the pneumatic connections are in G 1/4 (otherwise NPT).

Ground

Connect earth cable to screw #1 (or screw #2 in the electrical connection compartment).




PNEUMATIC CONNECTIONS

WARNING

To avoid any personal injury resulting from bursting of parts, do not exceed maximum supply pressure of positioner and actuator. To avoid any personal injury or property damage from sudden or fast movement, during air connection: **Do not put your finger or other part at any time inside the valve or in any moving part of the actuator or in the feedback lever mechanism. Do not touch the rear part of the positioner at any time.** Connect air supply only after connections y1 (and y2 for double acting) are done.

Air supply (s): 1.4 to 6 bar (but not more than the max. pressure of actuator), free of oil, dust and water !




3. ELECTRICAL CONNECTIONS



The safety requirements of document EX EVE0001 as well as the requirements of PSS EVE0105 and MI EVE0105 for SRD991 must be observed!

3.1 Setpoint Electric Terminal A

3.1.1 SRD991-xD (w/o communication) SRD991-xH (HART)




3.1.3 SRD991-xP (PROFIBUS PA) SRD991-xQ (FIELDBUS FF)




3.2 Inductive Limit Switch Electric Terminal C

3.2.1 SRD991-xxxT or U

Two-wire proximity sensors,
acc. to DIN 19234 or NAMUR



3.2.2 SRD991-xxxR




3.2.3 SRD991-xxxV

Warning: For connection of micro switches please refer to MI (Master Instruction) and obey the safety requirements described in document EX EVE0001.

3.3 Option Board Electric Terminal B


3.3.1 Two binary outputs (SRD991-xxP)

Two-wire system, acc. to DIN 19234
or switched output.




3.3.2 Two binary inputs (SRD991-xxB)

Binary inputs with internal supply for connection
of sensors or switches (switch **closed** for a
normal operation!)




3.3.3 Position feedback 4 to 20 mA and 1 Alarm (SRD991-xxQ ou SRD991-xxF)

Analog output 4-20 mA and Binary output Two-wire system acc. to DIN 19234 or switched.



3.3.4 Two binary in-/outputs (SRD991-xxE)

Two-wire system acc. to DIN 19234 or
switched in-/output.



* For intrinsically safe circuits please refer to certificate / data label for max. operating voltages etc.


4. START UP (Setting by means of local keys and LCD)

After mounting the positioner on the actuator, air and electrical input connected, you can start-up the SRD. The positioner can be adjusted by means of a local key-pad and LCD.

WARNING


*To avoid any personal injury or property damage from sudden or fast movement, during configuration:
Do not put your finger or other part at any time inside the valve or in any moving part of the actuator or in the feedback lever mechanism.
Do not touch the rear part of the positioner at any time.*

Push buttons



IN OPERATION:


An already configurated device may show the following display:



For configuration press (M) and Main menu appears.

CONFIGURATION with push buttons and LCD:


If the SRD wasn't configurated yet, the Main menu*) appears automatically after power-up:




(The selected item is displayed with dark background.)

In menu 1 you select the type of mounting: Press keys (UP)+(DOWN) simultaneously to enter this menu.


Select your 'Type of mounting' by pressing (UP) or (DOWN).



Press keys (UP)+(DOWN) simultaneously to confirm and save. The SRD moves back to Main menu again.



To enter next menu (= menu 2, Autostart) press (UP) once:



Now press keys (UP)+(DOWN) simultaneously to enter menu 'Autostart'.

(Continued on next page.)

*) On delivery the menu language in the display is English. The menu language can be changed over to another stored language. For this select 9.8.2 [German] or 9.8.3 [as ordered] and confirm with keys (UP)+(DOWN) (simultaneously). Leave menu by repeated pressing of (M) key.

Several Autostart options are available . Select relevant Autostart by pressing **(UP)** or **(DOWN)**:

- 2 Autostart
- 2.1 Endpoints
- 2.2 Standard**
- 2.3 Enhanced
- 2.4 Smooth resp.
- 2.5 Fast resp.

- Determines only the mechanical stops of actuator / valve
- **Recommended for standard applications**
- Optimized control behaviour compared to Standard Autostart
- Dampened control behaviour for e.g. smaller actuators
- Undampened control behaviour for e.g. larger actuators

Press keys **(UP)+(DOWN)** simultaneously to confirm and to launch Autostart. The automatic adaptation to the actuator is composed of a sequence of steps indicated on the LCD.

With the last step the device is **IN OPERATION**:

87.5 % Valve position	87.5 % Valve position Ctrl diff error	Diagnostic messages see following table.
---------------------------------	---	---

5 TROUBLE SHOOTING (For more details see MI EVE0105 E)

Autostart err 1	
Description of message / LCD text	Remedy
Air supply too low	Check air supply
Feedback lever (linear actuator) or Coupling (rotary actuator) incorrectly linked. Potentiometer moves out of operating range of $\pm 47^\circ$ of 0° position	Check mounting. Flat area points to arrow on housing
Coupling (rotary actuator) incorrectly linked (R and L interchanged)	Check mounting
Pneumatic output to actuator closed or untight. When direct mounting onto FlowTop or FlowPak, the screw plug y1-d is not removed	Check pneumatic connections
Mechanical stops not determinable	Check spring movement of actuator / check air supply / Check mounting
When using a booster or spool valve, no control parameters can be determined, since air capacity is too high	Device version is not suitable for this actuator; select version with smaller air capacity or remove booster
Control parameter too high since air capacity is too high (in general, oscillation in valve movement)	Use a booster or the version with spool valve. Reduce control parameter prop.-gain (Menu 6.1 and 6.2) to Code 10 = value 26.6.
Possibly incomprehensible configuration data	Reset configuration, see Menu 9.1

Optionboard err	
Description of message / LCD text	Remedy
Configured status of the SRD deviates from existing version (e.g. Option board has been inserted subsequently)	Check if correct option board has been connected Confirm message by pressing keys (UP)+(DOWN) simultaneously
Bad contact	Connections to terminals interchanged Check connections Tighten electronics
Defective	Exchange option board

Ctrl diff error	
Description of message / LCD text	Remedy
Actuator problems (high friction or blocked)	Check actuator
Insufficient air supply	Check air supply / air filter
Insufficient parameters for position controls, for example, amplification too small	Check control parameter, check pneumatic components
IP module or pneumatic amplifier defect	Check with Menu 7; replace if necessary

6 MENU STRUCTURE FOR SRD991 / SRD960

SRD Main Menu

Menu	Factory configuration	Description
1 Mounting	✓	1.1 Lin left 1.2 Lin right 1.3 Rot cclockw 1.4 Rot clockw 1.5 Linear
2 Autostart		Adaptation of the mechanical stops only Autostart recommended for standard application Enh. Autostart. Optimized control behaviour compared to Standard Autostart Enh. Autostart. Damped control behaviour for e.g. smaller actuators Enh. Autostart. Undamped control behaviour for e.g. larger actuators
3 Valve Action	✓	Action of Positioner: Valve opens with increasing setpoint value Valve closes with increasing setpoint value
	✓	Action of Feedback Unit: Increasing Current with increasing valve position Decreasing Current with increasing valve position
4 Character	✓	Linear characteristic Equal percentage characteristic 1:50 Inverse equal percentage characteristic 1:50 (quick opening) Custom characteristic (Configuration via DTM)
5 Limits/alarms		<i>(Not locally available with LED versions of communication FF and Profibus)</i>
	0 %	Closing limit is set to input value
	1 %	0%-tight sealing point is set to input value
	100 %	100%-tight sealing point is set to input value
	100 %	Opening limit is set to input value
	4 mA	Split range 0 %: input value corresponds to 0 %
	20 mA	Split range 100 %: input value corresponds to 100 %
	-10 %	Lower position alarm on output 1 is set to input value
	110 %	Upper position alarm on output 2 is set to input value
	4 mA	Configuration of rated-stroke of 0% at 4 mA
	20 mA	Configuration of rated-stroke of 100% at 20 mA
	x° / 20 mm	Configuration of nominal travel
	SI	Configuration of temperature and pressure unit SI or Anglo US
6 Parameters		
	15	P: Proportional gain for 'close valve'
	2	P: Proportional gain for 'open valve'
	7.5	I: Integration time for 'close valve'
	2.4	I: Integration time for 'open valve'
	0.35	T63: Setting time for 'close valve'
	0.35	T63: Setting time for 'open valve'
	0.1	Permitted dead band for control difference
7 Output		Manual setting of IP-Module for testing of pneumatic output
8 Setpoint		Manual setting of valve position
	8.1 12.5% Steps	Setpoint changes of 12.5% steps by using push buttons Up or Down
	8.2 1% Steps	Setpoint changes of 1% steps by using push buttons Up or Down
	8.3 Do PST	Start Partial Stroke Test

9 Workbench		
9.1 Reset Config		Resetting of configuration to setting "ex factory"
9.2 Calib. 4 mA		Calibrate input current to 4 mA
9.3 Calib. 20 mA		Calibrate input current to 20 mA
9.4 Calib. -45°		Calibrate position measuring value to -45°
9.5 Calib. +45°		Calibrate position measuring value to +45°
9.6 Reset all 1		Resetting of configuration and Calibration (!) to "ex factory" setting for single-acting output
9.7 Reset all 2	✓	Resetting of configuration and Calibration (!) to "ex factory" setting for double-acting output
9.8 Go Online		Setting position into mode Online (Service function only)
9.9 Menu Lang		Language on LCD:
9.9.1 English		Standard English
9.9.2 Deutsch		Standard German
9.9.3 Français		Preselected / freely definable
9.10 LCD orient	✓	LCD Orientation:
9.10.1 Normal		Normal orientation of writing on LCD
9.10.2 Flipped		Reverse orientation of writing on LCD
9.11 Cal. Feedbk		Calibration of output current of position transmitter
9.11.1 Cal. 4 mA		Calibration of 0% at 4 mA
9.11.2 Cal 20mA		Calibration of 100% at 20 mA
10 Profibus PA - Bus Address	126	Profibus only. Ratio from Dec. 0 / Hex 00 to Dec. 15 / Hex 0F Ratio from Dec. 0 / Hex 00 to Dec. 112 / Hex 70 Display of Bus Address from Dec. 1 to 127 (Hex 00 to 7F)
10 FOUNDATION Fieldbus H1		FF only.
10.1 Simulate	✓	Simulate disabled
10.2 Profile	✓	Simulate enabled
Disabled		Link Master active
Enabled		Link Master de-activated
Link Master		
Basic Device		

Invensys Systems, Inc.
38 Neponset Street
Foxboro, MA 02035
United States of America

schneider-electric.com

Global Customer Support
Toll free: 1-866-746-6477
Global: 1-508-549-2424
Website:
<http://support.ips.invensys.com>

Copyright 2010-2016 Invensys Systems, Inc.
All rights reserved.

Invensys, Foxboro, and I/A Series are trademarks of Invensys Limited, its subsidiaries, and affiliates. All other trademarks are the property of their respective owners.