

Warner GT-300

Installation and Troubleshooting Guide

P-2102-WE
819-0329



An **Altra Industrial Motion** Company

Terminology	2
GT300 Components	2-4
Mounting Requirements.....	5-6
Anti-Rotation Examples.....	7-9
Troubleshooting Checklist	10-11
Electrical Evaluation.....	12-13

This guide applies to Warner Electric GT-300 (GT780 frame) clutches and clutch/brakes used on power equipment.

Commercial GT780 is available in a range of Bore sizes, Pulley & output hub configurations.

This clutch/brake consists of an electromagnetic clutch with a mechanical brake which activates automatically when the clutch is turned off.

In addition to these general procedures, any applicable OEM general and safety procedures must also be followed.

⚠ WARNING

Failure to follow these instructions may result in product damage, equipment damage, and serious or fatal injury to personnel.

GT-300 (GT780 frame) Bearing Mounted Electric Clutch Terminology and Components:

(See Figure 1 on page 3.)

1. Rotor

Generally, the input of the clutch includes a keyed hub which mates with the keyway in the crank shaft. The rotor transmits the torque from the crankshaft (driving shaft) to the armature assembly (output).

2. Armature Assembly

Generally, the output of the clutch consists of a disk, springs and pulley (or output flange). With power applied the armature transmits torque from the rotor to the driven load. Power from the armature disk is transmitted to the pulley or flange by means of the leaf springs.

3. Field Assembly

The clutch "power" source contains the coil which generates magnetic attractive force.

4. Brake Ring

The brake ring is affixed to the field shell and provides the brake torque when the clutch is disengaged. The brake ring is not present if the assembly is a clutch only.

5. Anti-rotation Tab


Anti-rotation tab prevents the field from rotating with the crankshaft. If the field is bolted rigidly or if its axial movement is restricted the field bearing will be preloaded and fail prematurely.

6. Clamp Washer (Provided by customer)

A single .250 inch (6.35 mm) minimum thick steel washer must be used between the clutch and the crank shaft retaining bolt


⚠ WARNING **A washer less than .250 inch (6.35 mm) thick will deform and allow the clamping load to be lost, resulting in damage to the clutch and/or the crankshaft and possible personal injury due to clutch separating from the shaft. Multiple thinner washers are not acceptable.**

Typical Engine Installations with Output Pulley/or Bolt on Hub



Reverse Mount: Figure 1 refers to the pulley or flange being mounted towards the engine. The recommended shaft engagement for this configuration is 2.5 to 3.75 inches. This is recommended because it reduces the overhung load on the engine shaft. (Contact Warner Electric if minimum engagement can not be met.)

Standard Mount: Figure 2 refers to the pulley or flange hub being mounted away from the engine. The recommended shaft engagement for this configuration is 3.0 to 3.75 inches to insure shaft support under armature bearing.



See Anti-Rotation Examples on pages 7-9

CAUTION The Anti-Rotation device must allow both axial and radial free-play. If the field is bolted rigidly or if its axial movement is restricted (see Figure 3), the bearing in the field assembly will be improperly loaded and may fail prematurely.

Clutch/Brake Assemblies




Figure 4
View facing armature assembly




Figure 5
View facing field assembly

Mounting Requirements For A Successful Clutch Application/Installation

**The most important requirements for
a successful clutch application or
installation are:**

1. Anti-rotation device must allow both axial and radial free-play!

Failure to allow this free-play will result in field bearing failure. The greater the restriction the faster the bearing will fail!


2. The clutch has to bottom on flat surface, not in/on the radius of the engine shaft.
3. Ground-drive or spacer faces must be parallel within .003" and perpendicular to the bore.
4. Minimum mounting bolt size torqued to specification, confirm bolt does not bottom in drilled and tapped hole.
 - 7/16-20 UNF **Grade 8 bolt** torqued to 65-80 lb.-ft.
 - M 10 X 1.50 Class 10.9 torqued to 70-75 Nm

Note: All values are for dry (unlubricated) plated fasteners, please consult fastener manufacturer for torque specifications if any type of locking element (thread lock compound, patch etc.) is to be used.

WARNING Failure to adhere to these requirements will result in the failure of the clutch!

Mounting


Figure 6



Ground drive pulley or spacer must be chamfered to clear this radius on the engine shaft shoulder.

Figure 7

Ground drive pulley or spacer must be chamfered to clear this radius on the engine shaft shoulder.



▲CAUTION

Always bottom the clutch against a flat surface; never against a radius.

Anti-Rotation Example

Figure 8





Figure 9



Anti-Rotation Example

Figure 10





Figure 11



Anti-Rotation Example

Figure 12





Figure 13



Troubleshooting Checklist

A. Symptom: Clutch will not engage

Problem	Possible Causes	Solution
Blown fuse	<ul style="list-style-type: none"> • Low coil resistance • Defective battery • Faulty charging system • Bad wiring or connections, PTO switch 	<ul style="list-style-type: none"> • Replace clutch • Replace battery • Repair or replace • Repair or replace
Low voltage supply (Less than 12 VDC at clutch)	<ul style="list-style-type: none"> • Defective battery • Faulty charging system • Bad wiring or connectors, PTO switch 	<ul style="list-style-type: none"> • Replace • Repair or replace • Repair or replace
Incorrect coil resistance	<ul style="list-style-type: none"> • Damaged coil 	<ul style="list-style-type: none"> • Replace clutch
Inadequate current supply	<ul style="list-style-type: none"> • Broken clutch lead wire • Faulty electrical system • Measure clutch coil resistance and supply voltage at the clutch. If both are correct, electrical system is faulty. 	<ul style="list-style-type: none"> • Repair • Repair or replace • Repair
Rotor/armature air-gap too large	<ul style="list-style-type: none"> • Rotor/armature wear; end of usable life 	<ul style="list-style-type: none"> • Replace clutch only • Adjust or replace clutch brake

B. Symptom: Brake will not engage

Problem	Possible Causes	Solution
Armature/brake ring worn out	<ul style="list-style-type: none"> • End of usable life 	<ul style="list-style-type: none"> • Replace clutch
Contaminated friction surfaces	<ul style="list-style-type: none"> • Engine oil leak on brake 	<ul style="list-style-type: none"> • Repair leak, clean armature and brake
Brake ring/Out of adjustment	<ul style="list-style-type: none"> • Out of adjustment • Wear 	<ul style="list-style-type: none"> • Adjust brake

C. Symptom: Clutch slip

Problem	Possible Causes	Solution
Low voltage supply (less than 12 VDC at clutch)	<ul style="list-style-type: none"> • Defective battery • Faulty charging system • Bad wiring or connectors, PTO switch 	<ul style="list-style-type: none"> • Replace • Repair or replace • Repair or replace
Inadequate current supply	<ul style="list-style-type: none"> • Broken clutch lead wire • Faulty electrical system 	<ul style="list-style-type: none"> • Repair • Measure clutch coil resistance and supply voltage at the clutch. If both are correct, electrical system is faulty. Repair or replace.
Overloaded clutch	<ul style="list-style-type: none"> • Clogged deck, bad spindle, etc. 	<ul style="list-style-type: none"> • Remove excess grass • Replace spindle
Contaminated friction surfaces	<ul style="list-style-type: none"> • Engine oil leak on clutch 	<ul style="list-style-type: none"> • Repair leak • Replace or clean clutch friction faces

Troubleshooting Checklist (Continued)

D. Symptom: Noisy clutch/Vibration

Problem	Possible Causes	Solution
Failed bearing	<ul style="list-style-type: none"> • Loose mounting (bolt not torqued properly) • Field assembly movement restricted 	<ul style="list-style-type: none"> • Replace clutch and/or bearing • Confirm proper Anti-rotation (see Anti-rotation pages)
Anti-rotation rattles	<ul style="list-style-type: none"> • Some noise is normal 	<ul style="list-style-type: none"> • If noise is excessive, repair or replace anti-rotation pin anti-rotation device (Follow OEM's Specifications. (See Anti-rotation)).
Clutch loose on shaft	<ul style="list-style-type: none"> • Loose mounting (bolt not torqued properly) • Mounting bolt too long and bottoms out • Mounting washer too thin and deforms • Shaft bottoms on retaining washer when bolt is tightened 	<ul style="list-style-type: none"> • Tighten mounting bolt to specification. See Mounting bolt torque page 5 • Use correct length bolt (see in engine shaft before clamping clutch) • See Warning below • Use proper spacer (see Mounting page)
Clutch not mounted square	<ul style="list-style-type: none"> • Ground Drive Spacer mounting shoulder out of spec • Clutch key hitting end of keyway • Incorrect or no chamfer on ground 	<ul style="list-style-type: none"> • Replace • Space clutch away from radius in shaft in engine shaft keyway. • Increase chamfer on ground drive spacer.
Broken Spring	<ul style="list-style-type: none"> • Loose mounting (bolt not torqued properly) • Installed for incorrect direction of rotation 	<ul style="list-style-type: none"> • Replace clutch • Replace clutch and correct direction of rotation

⚠ WARNING A washer less than .250 inch (6.35 mm) thick will deform and allow the clamping load to be lost, resulting in damage to the clutch and/or the crankshaft and possible personal injury due to clutch separating from the shaft. Multiple thinner washers are not acceptable.

Procedure for Air gapping Warner GT-300

Bench setting:

1. Remove clutch from tractor.
2. Loosen but do not remove the three brake mounting screws. Insert a 0.015" feeler gauge or equivalent thickness shim stock at each screw location being careful to locate the gauge between the armature and brake ring. (Figure 14 and 15)
3. With all three feeler gauges in place, apply 12 volts to engage the clutch against the shims. While depressing the brake ring to the back of the armature at each mounting screw location, tighten the mounting screw to 140 in.lbs.
4. Remove the 12 volts applied to the clutch and remove the feeler gauges. Turn the rotor assembly to check for rotor /armature drag. The rotor should turn freely.
5. Due to dimensional variations, the airgap between the rotor and armature may vary on a clutch from .025" to .005", even though the gap at the three studs was set at 0.015". This is an acceptable condition.
6. Using the feeler gauges check the airgap at the stud locations. If the airgap does not fall between .025/.005", repeat the procedure outlined in steps 1-5 above.

Setting air gap on the engine crankshaft

The clutch should be mounted to engine crankshaft and secured with appropriate bolt and washer with a minimum thickness of .250". Mounting bolt torqued to specification, confirm bolt does not bottom in drilled and tapped hole:

- 7/16-20 UNF **Grade 8 bolt** torqued to 65-80 lb.-ft.
- M 10 X 1.50 Class 10.9 torqued to 70-75 Nm

Follow steps 2-6 listed above to set airgap.

Electrical check for Warner GT-300 clutches

Coil resistance:

1. Turn engine and PTO switch off.
2. Disconnect clutch wire connection.
3. Select meter setting to ohms.
4. Connect meter lead wires to the terminals of the clutch (Figure 14)




Figure 14

5. If meter reads between 1.82 ohms and 2.03 ohms the coil is within specifications. If it falls below 1.8 or above 2.03 ohms the field needs to be replaced. Reading must be taken at room temperature (approximately 68-72 degrees F).

Clutch current draw at 12 volts

1. Turn off engine.
2. Disconnect clutch wire on one terminal, leaving other wire "D" connected to the clutch "B". (Figure 16)
3. Select meter to check amps (10-amp scale).
4. Connect one meter lead wire to the clutch at "A" (Figure 16)
5. Connect the other meter lead wire to the corresponding wire from the harness at "C" (Figure 16)
6. Turn PTO switch on.
7. If meter reads below 6 amps, the problem would be in the electrical system leading to the clutch (battery, relay, switch, etc.).

NOTE: All values taken at room temperature. Voltage at 12VDC. As temperature increases, resistance increases, and current decreases.




Figure 15

Burnish Procedure

1. Run engine at approximately 25% throttle (higher RPM may be necessary if engine stalls)
2. Engage clutch, bring load up to engine RPM. Disengage and let load come to a complete stop. Repeat twelve (12) times.
3. Repeat step two at 50% throttle for five (5) cycles.
4. Increase engine RPM to full throttle and engage and disengage as in step 2 repeating five (5) times.




Figure 16

Warranty

Warner Electric LLC warrants that it will repair or replace (whichever it deems advisable) any product manufactured and sold by it which proves to be defective in material or workmanship within a period of one (1) year from the date of original purchase for consumer, commercial or industrial use.

This warranty extends only to the original purchaser and is not transferable or assignable without Warner Electric LLC's prior consent.

Warranty service can be obtained in the U.S.A. by returning any defective product, transportation charges prepaid, to the appropriate Warner Electric LLC factory. Additional warranty information may be obtained by writing the Customer Satisfaction Department, Warner Electric LLC, 449 Gardner Street, South Beloit, Illinois 61080, or by calling 815-389-3771.

A purchase receipt or other proof of original purchase will be required before warranty service is rendered. If found defective under the terms of this warranty, repair or replacement will be made, without charge, together with a refund for transportation costs. If found not to be defective, you will be notified and, with your consent, the item will be repaired or replaced and returned to you at your expense.

This warranty covers normal use and does not cover damage or defect which results from alteration, accident, neglect, or improper installation, operation, or maintenance.

Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Warner Electric LLC's obligation under this warranty is limited to the repair or replacement of the defective product and in no event shall Warner Electric LLC be liable for consequential, indirect, or incidental damages of any kind incurred by reason of the manufacture, sale or use of any defective product. Warner Electric LLC neither assumes nor authorizes any other person to give any other warranty or to assume any other obligation or liability on its behalf.

WITH RESPECT TO CONSUMER USE OF THE PRODUCT, ANY IMPLIED WARRANTIES WHICH THE CONSUMER MAY HAVE ARE LIMITED IN DURATION TO ONE YEAR FROM THE DATE OF ORIGINAL CONSUMER PURCHASE. WITH RESPECT TO COMMERCIAL AND INDUSTRIAL USES OF THE PRODUCT, THE FOREGOING WARRANTY IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED BY OPERATION OF LAW OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Changes in Dimensions and Specifications

All dimensions and specifications shown in Warner Electric catalogs are subject to change without notice. Weights do not include weight of boxing for shipment. Certified prints will be furnished without charge on request to Warner Electric.



www.warnerelectric.com

4578 East Park 30 Drive
Columbia City, IN 46725
260-244-6183
Fax: 815-389-2582

An **Altra Industrial Motion** Company



www.altramotion.com