



Type 584, Actuator 45 and Actuator 46



Actuator 45 (NO), flow below the seat




Measurement and weight table Actuator type 45 and 46

DN	SW	V ₁	Total weight ca. (kg)
15	36	130	0,8
20	41	136	1,1
25	46	140	1,2


Valve body types see page 104 - 105

Control equipment and accessories see page 108 - 115

Actuator 45 (DA), flow below the seat



Actuator 46 (NC), flow above the seat



Working pressure normally closed (Cf. 1), flow below the seat as well as Working terms, see table page 96.
All pressures are gauge pressures.